



**Step:**

Connect the legs (B and C) onto the corners of the apron, by using the washers (E) and nuts (D) to join the bolts which fixed on the legs. And tighten them firmly with the wrench (F).

