


Assembly Instruction






Thank you for purchasing this product. This product has been designed for easy assembly and constructed for durability. Please take the time to read and follow the assembly instruction carefully.

PART LIST

NO	DESCRIPTION	QTY
A	TABLE TOP	1
B	TABLE LEG	4

HARDWARE LIST

NO.	DESCRIPTION	QTY
C	FLAT WASHER	8PCS
D	SPRING WASHER	8PCS
E	HEXAGON NUT	8PCS
F	SPANNER	1PCS

IMPORTANT NOTE :

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched. Check to be sure that you have all parts and hardware. Remove all wrapping materials, including staples & packing straps before you start to assemble. Do not tighten all screws / bolts until all completely assembled. Keep all hardware parts out of reach of children.

SCREWS MUST BE TIGHTEN PERIODICALLY. SCREWS MAY COME LOOSE.
CHECK THE TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.